

## Stagecaptain CBW-45 NT Couchbar mit 4 Fächern

ArtNr.: 00100099

Vielen Dank, dass Sie sich für unsere Couchbar (ArtNr. 00100099) entschieden haben. Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bitte Sicherheitshinweise beachten!



Mit dem Signalwort WARNUNG sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



### **Detailierte Sicherheitshinweise:**

Bitte beachten Sie die folgenden Sicherheitshinweise um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

- Diese Artikel sind keine Kinderspielzeuge und sind für Kinder unter 3 Jahren nicht empfohlen. Lassen Sie Ihre Kinder nicht unbeaufsichtigt mit den Produkten spielen.
- Bitte Zweckentfremden Sie die Couchbar nicht (z.B. als Stiege, Backform, Kühlschrankaufbewahrung o. ä.)
- Die Holzoberflächen sind möglichst glatt gearbeitet. Dennoch hat Holz naturgemäß immer Kanten oder Bohrungen sowie
  ggf. Spreißel, die zu Verletzungen führen können. Lassen Sie bitte Vorsicht walten.
- Nutzen Sie für Verköstigungszwecke bitte nur die Metallschalen der Couchbar, die Holzfächer sind nur zur Ablage von Gebrauchsgegenständen (Mobiltelefon, Fernbedienung) oder in Tüten verpackten Lebensmitteln geeignet.
- Achten Sie beim Einsetzen und entnehmen der Metallschalen darauf, dass sich keine Gegenstände, Gliedmaße oder Essensreste in den Öffnungen für die Schalen befindet. Unsachgemäße Handhabung kann zu eingeklemmten Gliedmaßen führen.

#### PFLEGEHINWEISE / HOLZ

Holz ist ein Naturprodukt. Die Couchbar ist nur für den Gebrauch in Innenräumen oder auch draußen (bei entsprechend trockener Witterung) konzipiert. Wir empfehlen die Couchbar lediglich mit einem trockenen Tuch zu reinigen. Die Metallschalen können mit warmem Wasser per Hand mit einem Schwamm gereinigt werden.

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen.

KIRSTEIN.de Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau - Germany

Telefon/Phone: 0049-8861-909494-0

Version: 11.2023



# Stagecaptain CBW-45 NT Couchbar with 4 compartments

Item no.: 00100099

Thank you for purchasing our Couchbar (Item no. 00100099). To ensure that you are fully satisfied with this product, please read and understand these operating instructions carefully before using our product. Keep these operating instructions in a safe place. The operating instructions must be passed on to all subsequent users.



Please observe the safety instructions!



The signal word WARNING indicates dangers that could lead to serious injury if precautions are not taken.



All personal formulations in these operating instructions are to be regarded as gender-neutral.

All information in these operating instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damage arising in connection with the use of these operating instructions.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.



### **Detailed safety instructions:**

Please observe the following safety instructions to avoid malfunctions, damage or injury:

- This item is not a children's toy and is not recommended for children under 3 years of age. Do not allow your children to
  play with the product unsupervised.
- Please do not use the couchbar for other purposes (e.g. as a staircase, baking pan, refrigerator storage, etc.)
- The wooden surfaces are crafted as smooth as possible. Nevertheless, wood naturally always has edges or drill holes as well as splinters that can lead to injuries. Please exercise caution.
- Please only use the metal trays on the couch bar for food and drink, the wooden compartments are only suitable for storing everyday objects (cell phone, remote control) or food packed in bags.
- When inserting and removing the metal trays, make sure that there are no objects, limbs or food residues in the openings for the trays. Improper handling can lead to trapped limbs.

#### CARE INSTRUCTIONS / WOOD

Wood is a natural product. The couch bar is designed for indoor use only or for outdoor use (in dry weather conditions). We recommend cleaning the couch bar with a dry cloth only. The metal bowls can be cleaned by hand with warm water and a sponge.

All technical data and appearances are subject to change without prior notice. All information was correct at the time of printing. Musikhaus Kirstein GmbH assumes no liability for the accuracy or completeness of the descriptions, photos or statements contained in this manual. Printed colors and specifications may differ slightly from the product.

KIRSTEIN.de Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau - Germany

Telefon/Phone: 0049-8861-909494-0

Version: 11.2023