

CLASSIC CANTABILE

GS-8 Glockenspiel

ArtNr.: 00062902

Vielen Dank, dass Sie sich für unser GS-8 Glockenspiel entschieden haben. Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bitte Sicherheitshinweise beachten!



WARNUNG

Mit dem Signalwort WARNUNG sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



HINWEIS

Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



WARNUNG

Detaillierte Sicherheitshinweise:

Bitte beachten Sie die folgenden Sicherheitshinweise um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

- Diese Artikel sind keine Kinderspielzeuge und sind für Kinder unter 3 Jahren nicht empfohlen. Lassen Sie Ihre Kinder nicht unbeaufsichtigt mit den Produkten spielen. Gefahr wegen verschluckbarer Kleinteile.
- Nicht in Ohrnähe anwenden. Missbrauch kann zu Gehörschaden führen.

PFLEGEHINWEISE / HOLZ

Holz ist ein Naturprodukt. Das GS-8 Glockenspiel ist nur für den Gebrauch in Innenräumen oder auch draußen (bei entsprechend trockener Witterung) konzipiert. Wir empfehlen das GS-8 Glockenspiel lediglich mit einem trockenen Tuch zu reinigen.

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen.

© 2024

Diese Bedienungsanleitung ist urheberrechtlich geschützt. Die Vervielfältigung dieser Bedienungsanleitung, auch auszugsweise, ist nur mit Genehmigung der Musikhaus Kirstein GmbH gestattet. Gleiches gilt für die Vervielfältigung oder das Kopieren von Bildern, auch in geänderter Form.

 **KIRSTEIN.de**

We love music!

Musikhaus Kirstein GmbH
Bernbeurener Str. 11
86956 Schongau – Germany
Telefon: 0049-8861-909494-0
E-Mail: info@kirstein.de



Version: 03.2024

CLASSIC CANTABILE

GS-8 Glockenspiel

ArtNr.: 00062902

Thank you for purchasing our GS-8 Glockenspiel. To ensure that you are fully satisfied with this product, please read and understand these operating instructions carefully before using our product. Keep these operating instructions in a safe place. The operating instructions must be passed on to all subsequent users.



Please observe the safety instructions!



WARNING

The signal word WARNING indicates dangers that could lead to serious injury if precautions are not taken.



NOTE

All personal formulations in these operating instructions are to be regarded as gender-neutral.

All information in these operating instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damage arising in connection with the use of these operating instructions.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.



WARNING

Detailed safety instructions:

Please observe the following safety instructions to avoid malfunctions, damage or injury:

- These items are not toys and are not recommended for children under the age of 3. Do not let your children play with the products unsupervised. Risk of swallowing small parts.
- Do not use near the ear. If misused, this can lead to hearing damage.

CARE INSTRUCTIONS / WOOD

Wood is a natural product. The GS-8 Glockenspiel is designed for indoor use only or for outdoor use (in dry weather conditions). We recommend cleaning the GS-8 Glockenspiel with a dry towel only.

All technical data and appearances are subject to change without prior notice. All information was correct at the time of printing. Musikhaus Kirstein GmbH assumes no liability for the accuracy or completeness of the descriptions, photos or statements contained in this manual. Printed colors and specifications may differ slightly from the product.

© 2024

These instructions for use are protected by copyright. Reproduction of these operating instructions, even in part, is only permitted with the permission of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, including in modified form.

 **KIRSTEIN.de**

We love music!

Musikhaus Kirstein GmbH
Bernbeurener Str. 11
86956 Schongau – Germany
Telefon: 0049-8861-909494-0
E-Mail: info@kirstein.de

