

Stagecaptain Beer Pong Tische

ArtNr.: 00076335/00076336/00076337

Vielen Dank, dass Sie sich für unsere Beer Pong Tische (ArtNr.: 00076335/00076336/00076337) entschieden haben. Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bitte Sicherheitshinweise beachten!



Mit dem Signalwort **WARNUNG** sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Diese Bedienungsanleitung gilt für Personen, die von einer für ihre Sicherheit verantwortlichen Person beaufsichtigt oder in die Bedienung des Artikels eingewiesen wurden.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



Detaillierte Sicherheitshinweise:

Bitte beachten Sie die folgenden Sicherheitshinweise um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

- Diese Artikel sind keine Kinderspielzeuge und sind für Kinder unter 3 Jahren nicht empfohlen. Lassen Sie Ihre Kinder nicht unbeaufsichtigt mit den Produkten spielen.
- Hüpfen, Herumturnen und Kippen kann zum Bruch bzw. zum Umfallen der Tische führen und Verletzungen verursachen. Bitte verhindern Sie unbedingt, dass sich Personen auf die Tische setzen, da diese sonst durchbrechen.
- Die Aluminium Applikationen sind möglichst glatt gearbeitet. Dennoch können die Tische unsaubere Kanten, Spreißel oder Abrieb aufweisen, der zu Verletzungen führen kann. Lassen Sie bitte Vorsicht walten.
- Nutzen Sie die Tische oder Bänke zu Verköstigungszwecken, so legen Sie immer eine lebensmittelechte Unterlage (Geschirr oder die mitgelieferten Becher) zwischen Nahrungsmittel und Holzoberflächen.
- Achten Sie beim Aufbau und Umklappen des Tisches und der Scharnier Füße auf den Klappmechanismus. Unsachgemäße Handhabung kann zu eingeklemmten Gliedmaßen führen.
- Zweckentfremden Sie diese Produkte nicht (z.B. als Leiter, Rutschbahn, Gestell o. ä.).

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen.

Wie wird Beer Pong gespielt?

Eine umfassende Beer Pong Spielanleitung finden Sie unter: https://de.wikipedia.org/wiki/Beer_Pong

 **KIRSTEIN.de**
Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau – Germany

Telefon/Phone: 0049-8861-909494-0

Telefax/Fax: 0049-8861-909494-19

Stagecaptain Beer Pong Tables

ArtNr.: 00076335/00076336/00076337

Thank you for choosing our products (00076335/00076336/00076337). To ensure that you are fully satisfied with this product, please read carefully and understand these operating instructions before using our product. Keep these operating instructions in a safe place. The manual must be passed on to all subsequent users.



Please observe the safety instructions!



WARNING

The signal word WARNING indicates dangers which can lead to serious injury if no precautionary measures are taken.



NOTE

All personal formulations in these operating instructions are to be considered gender-neutral.

This instruction manual applies to persons who have been supervised or instructed in the operation of the article by a person responsible for their safety.

All information in this manual has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damages in connection with the use of this manual.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. The user of this document is responsible for compliance with all applicable copyright laws.



WARNING

Detailed safety instructions:

Please observe the following safety instructions to avoid malfunctions, damage or injury:

- These articles are no toys for children and are not recommended for kids under 3 years of age. Do not leave your children to play with these products unattended.
- Jumping, gymnastics and tilting can cause the tables to break or fall over and cause injuries. Please prevent people from sitting on the tables at all costs, otherwise they will break.
- The aluminium applications are made as smooth as possible. However, the tables may still have unclean edges, splinters or abrasion that can cause injury. Please take care here.
- If you use the tables or benches for eating, always place a food-safe surface (dishes or the included plastic cups) between food and wooden surfaces.
- Pay attention to the folding mechanism when setting up and folding down the table and the hinge feet. Improper handling can lead to trapped limbs.
- Do not use these products for other purposes (e.g. as a ladder, slide, stand, etc.).

All technical data and appearances can be changed without prior notice. All information was correct at the time of going to press. Musikhaus Kirstein GmbH does not guarantee the correctness or completeness of the descriptions, photos or statements contained in this manual. Printed colours and specifications may differ slightly from the product.

How to play Beer Pong?

Comprehensive Beer Pong game instructions can be found at: https://en.wikipedia.org/wiki/Beer_pong

 **KIRSTEIN.de**
Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau - Germany

Telefon/Phone: 0049-8861-909494-0

Telefax/Fax: 0049-8861-909494-19