

joycraft 3x8L 3-fach Getränkespender

ArtNr.: 00080003

Vielen Dank, dass Sie sich für unseren Getränkespender entschieden haben (ArtNr.: 00080003). Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bitte Sicherheitshinweise beachten!



Mit dem Signalwort **WARNUNG** sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Diese Bedienungsanleitung gilt für Personen, die von einer für ihre Sicherheit verantwortlichen Person beaufsichtigt oder in die Bedienung des Artikels eingewiesen wurden.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



Detaillierte Sicherheitshinweise:

Bitte beachten Sie die folgenden Sicherheitshinweise um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

- Dieser Artikel ist kein Kinderspielzeug. Lassen Sie Ihre Kinder nicht unbeaufsichtigt mit dem Artikel spielen.
- Unsachgemäßer oder Wackeliger Aufbau kann zum Bruch bzw. zum Umfallen des Getränkependers führen und Verletzungen verursachen.
- Die Aluminium Applikationen sind möglichst glatt gearbeitet. Dennoch können die Teile unsaubere Kanten, Spreißel oder Abrieb aufweisen, der zu Verletzungen führen kann. Lassen Sie bitte Vorsicht walten.
- Bitte reinigen Sie den Getränkespender nur mit lauwarmem Wasser und per Hand. Reinigen Sie die Teile bitte nicht mit aggressiven Reinigungsmitteln oder in der Spülmaschine. Vor dem ersten und nach jedem Gebrauch waschen. Zum Reinigen sauberes Wasser durch den Auslauf laufen lassen.
- Zweckentfremden Sie diese Produkte nicht (z.B. zum Einfüllen von anderen Flüssigkeiten als Getränken).
- Bitte befüllen Sie die Eis-Säule zuerst mit Eiswürfeln und dann den Behälter mit Wasser, sodass die Säule stabil steht und nicht durch das Vakuum an die Oberfläche geschwemmt wird.
- **ACHTUNG: Bitte füllen Sie KEINE heißen Flüssigkeiten in den Getränkespender, da dieser sonst kaputt gehen kann. Zudem besteht ein hohes Risiko sich durch heiße Flüssigkeiten Verbrennungen hinzuzufügen!**

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen.

 **KIRSTEIN.de**
Musikhaus Kirstein GmbH
Bernbeurener Str. 11
86956 Schongau – Germany
Telefon/Phone: 0049-8861-909494-0
Telefax/Fax: 0049-8861-909494-19

joycraft 3x8L 3-compartment Drink Dispenser

ArtNr.: 00080003

Thank you for choosing our products (00080003). To ensure that you are fully satisfied with this product, please read carefully and understand these operating instructions before using our product. Keep these operating instructions in a safe place. The manual must be passed on to all subsequent users.



Please observe the safety instructions!



WARNUNG

The signal word **WARNING** indicates dangers which can lead to serious injury if no precautionary measures are taken.



HINWEIS

All personal formulations in these operating instructions are to be considered gender-neutral.

This instruction manual applies to persons who have been supervised or instructed in the operation of the article by a person responsible for their safety.

All information in this manual has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damages in connection with the use of this manual.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. The user of this document is responsible for compliance with all applicable copyright laws.



WARNUNG

Detailed safety instructions:

Please observe the following safety instructions to avoid malfunctions, damage or injury:

- This article is no toy for children. Do not leave your children to play with these products unattended.
- Improper or wobbly assembly can cause the beverage dispenser to break or fall over and cause injuries.
- The aluminium applications are made as smooth as possible. However, the parts may still have unclean edges, splinters or abrasion that can cause injury. Please take care here.
- Please clean the beverage dispenser only with lukewarm water and by hand. Please do not clean the parts with aggressive cleaning agents or in the dishwasher. Wash before first and after every use. Run clean water through the spout to clean.
- Do not misuse these products (e.g. to fill them with liquids other than drinks).
- Please fill the ice column with ice cubes first and then fill the container with water so that the column stands stable and is not washed to the surface by the vacuum.
- **ATTENTION: Please do NOT pour hot liquids into the beverage dispenser, otherwise it may break. There may also be high risk of getting burned by hot liquids!**

All technical data and appearances can be changed without prior notice. All information was correct at the time of going to press. Musikhaus Kirstein GmbH does not guarantee the correctness or completeness of the descriptions, photos or statements contained in this manual. Printed colours and specifications may differ slightly from the product.

 **KIRSTEIN.de**

Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau - Germany

Telefon/Phone: 0049-8861-909494-0

Telefax/Fax: 0049-8861-909494-19

Aufbauanleitung / Assembly Instructions

