

# CLASSIC CANTABILE

## Classic Cantabile FML-32 Melodica, 32 Tasten

ArtNr.: 00086374/00086377/00086379

Vielen Dank, dass Sie sich für unsere Melodica entschieden haben. Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bitte Sicherheitshinweise beachten!



Mit dem Signalwort **WARNUNG** sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Diese Bedienungsanleitung gilt für Personen, die von einer für ihre Sicherheit verantwortlichen Person beaufsichtigt oder in die Bedienung des Artikels eingewiesen wurden.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



### Detaillierte Sicherheitshinweise:

Bitte beachten Sie die folgenden Sicherheitshinweise um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

- Diese Artikel sind keine Kinderspielzeuge und sind für Kinder unter 3 Jahren nicht empfohlen. Lassen Sie Ihre Kinder nicht unbeaufsichtigt mit den Produkten spielen.
- Es besteht Erstickungsgefahr bei beigelegten Kleinteilen.

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen.



- Bitte essen nichts bevor sie die Melodica spielen, Essensreste und Krümel können in die Kanzellen der Melodica fallen.
- Idealerweise spülen Sie Ihren Mund vor dem Harmonikaspielen mit klarem Wasser aus um Verschmutzungen durch Krümel oder Essensreste vorzubeugen.
- Bitte reinigen Sie die Melodica nur mit einem trockenen Tuch. Schütteln Sie Staub oder Krümel entsprechend ab oder blasen diese aus.
- Lagern Sie die Melodica an einem trockenen Ort und idealerweise immer in der Melodicatasche.

 **KIRSTEIN.de**  
Musikhaus Kirstein GmbH  
Bernbeurener Str. 11  
86956 Schongau – Germany  
Telefon/Phone: 0049-8861-909494-0  
Telefax/Fax: 0049-8861-909494-19

# CLASSIC CANTABILE

## Classic Cantabile FML-32 Melodica, 32 Tasten

ArtNr.: 00086374/00086377/00086379

Thank you for choosing our melodica. To ensure that you are fully satisfied with this product, please read carefully and understand these operating instructions before using our product. Keep these operating instructions in a safe place. The manual must be passed on to all subsequent users.



Please observe the safety instructions!



**WARNING**

The signal word WARNING indicates dangers which can lead to serious injury if no precautionary measures are taken.



**NOTE**

All personal formulations in these operating instructions are to be considered gender-neutral.

This instruction manual applies to persons who have been supervised or instructed in the operation of the article by a person responsible for their safety.

All information in this manual has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damages in connection with the use of this manual.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. The user of this document is responsible for compliance with all applicable copyright laws.



**WARNING**

### Detailed safety instructions:

Please observe the following safety instructions to avoid malfunctions, damage or injury:

- These articles are no toys for children and are not recommended for kids under 3 years of age. Do not leave your children to play with these products unattended.
- There is a risk of suffocation if small parts are included.

All technical data and appearances can be changed without prior notice. All information was correct at the time of going to press. Musikhaus Kirstein GmbH does not guarantee the correctness or completeness of the descriptions, photos or statements contained in this manual. Printed colours and specifications may differ slightly from the product.



**NOTE**

- Please do not eat anything before playing the melodica, food remains and crumbs can fall into the comb of the melodica.
- Ideally, you should rinse your mouth with clean water before playing the melodica to prevent contamination by crumbs or food residues.
- Please clean the melodica only with a dry cloth. Shake off dust or crumbs accordingly or blow them out.
- Store the melodica in a dry place and ideally always in the melodica box.

**KIRSTEIN.de**  
Musikhaus Kirstein GmbH  
Bernbeurener Str. 11  
86956 Schongau - Germany  
Telefon/Phone: 0049-8861-909494-0  
Telefax/Fax: 0049-8861-909494-19