

Pronomic SPS-C-8AS Distanzstange mit Kurbel

Art. No.: 00080330



Bedienungsanleitung

Revision: 05/2022

These operating instructions are protected by copyright. Reproduction of these operating instructions, even in part, is only permitted with the consent of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, even in modified form.

Content

Specifications	1
Intended use	3
Mounting	4

Specifications

Part number	00080330
Maximum load capacity	50kg
Adjustable height	840 - 1365mm
Thread	M20
Weight	3,2kg
Product type	Spacer rod with crank
Pipe material	Steel & Aluminium
Color	Black
Pipe surface	Powder coated
Connecting material	Die-cast aluminium
Crankcase material	Die-cast aluminium
Strut material	Steel
Diameter loudspeaker flange	35 mm
Tube diameter	45 mm / 41 mm / 38 mm



Musikhaus Kirstein GmbH
Bernbeurener Str. 11
86956 Schongau - Germany
Telefon/Phone: 0049-8861-909494-0
Fax/Fax: 0049-8861-909494-19



Thank you for choosing this product.

To ensure that you are completely satisfied with this product, please read carefully and understand this instruction manual before using our product. Keep these operating instructions in a safe place. The operating instructions must be passed on to all subsequent users.



Observe the operating instructions!



The signal word **WARNING** indicates hazards that can lead to serious injuries if no precautionary measures are taken.



The signal word **NOTE** indicates general precautions that should be observed when handling the product.



Images and screen representations in this manual may differ slightly from the appearance of the actual product, as long as this does not negatively affect the technical characteristics and safety of the product.



All person-related formulations in these operating instructions are to be regarded as gender-neutral.

These operating instructions apply to persons who have been supervised or instructed in the operation of the device by a person responsible for their safety and who have proven that they can handle the device.



**Children should be supervised to ensure that they do not play with the appliance.
Do not leave children unattended.**

All information in these operating instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damages in connection with the use of these operating instructions.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.

Intended use

WARNUNG

- Only use the product in accordance with the instructions given here. In the event of damage caused by failure to observe these instructions for use, the warranty will be invalidated! Musikhaus Kirstein GmbH accepts no liability for any resulting damage.
- Unauthorized conversions or modifications to the product are not permitted for safety reasons and will also void the warranty.
- Loudspeaker systems can tip over and cause injuries and property damage. Therefore, keep the immediate area around the speaker system clear and make sure that no persons are in this area.
- Only mount the distance tube on subwoofers or similar which are placed on flat and solid surfaces and which can bear the weight of the speakers. Ideally, you should then check the vertical alignment with the aid of a spirit level.
- Do not move the spacer tube when speaker cabinets are on it.
- Make sure that the load is evenly distributed on the spacer tube and that the specified maximum load capacity is not exceeded.
- Make sure that the installation complies with the standards and regulations in force in your country.
- This product is intended for indoor use only.
- Check the item for possible damage before commissioning. If the spacer tube is defective, it must not be put into operation.
- You can use a slightly damp cloth for cleaning.
- When setting up, also follow the installation instructions for your speakers and subwoofers.
- Determine a suitable location and set up the stand securely. The stand may only be set up on a stable and solid surface. An appropriate substructure may have to be provided.

Mounting

1. Screw the spacer tube into the thread on the top of a subwoofer (picture A) and check that the spacer tube has no play and therefore does not wobble or stand crooked.
2. Attach your speaker to the top end of spacer tube (picture B).
3. Loosen the crank handle set screw (Figure C).
4. Now you can bring your loudspeaker to the desired height with the help of the crank (picture D).
5. Finally, tighten the locking screw (picture C) again once the speaker box is at the desired height to provide additional safety.
6. The disassembly is carried out in reverse order.

