

1.

BASS

Use the bass control for low frequency adjustment, turn left for decreasing low frequencies and turn right for increasing low frequencies.

2.

TREBLE

Use the treble control for high frequency adjustment, turn left for decreasing high frequencies and turn right for increasing high frequencies.

3.

VOLUME

With the volume control it's possible to adjust the input sensitivity, turn left for decreasing the input sensitivity and turn right for increasing the input sensitivity.

4.

POWER SWITCH

Turns the loudspeaker on/off. Make sure the volume knob is set to minimum before turning it on!

5.

POWER INPUT

Connect the included power adapter to this input and connect the other end of the cable to a power source.

6.

OUTPUT

RCA connector for slave speaker (right).

7.

INPUT

RCA input left and right.

8.

Bluetooth:

To pair with Bluetooth, first press the Bluetooth button until the Bluetooth blinks, then turn on the Bluetooth Settings on your mobile device, search the list of "MTO3B" devices, select it, and complete the pairing process. Once the pairing is complete, the Bluetooth button will be fixed in blue and you can enjoy the transmission from your mobile device. If you press the bluetooth button again, it will turn off.

Pronomic MSS-2014 Winkelfuß-Lautsprecherstativ

ArtNr.: 00095049 (1 Paar Schwarz) Version: 05.2023

Vielen Dank, dass Sie sich für unser Lautsprecherstativ entschieden haben. Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie unser Produkt verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bedienungsanleitung beachten!




WARNUNG

Dies ist kein Spielzeug. Bitte lassen Sie Kinder nicht unbeaufsichtigt beim Umgang mit diesem Artikel.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Detaillierte Sicherheitshinweise/Verwendung:



HINWEIS

Bitte beachten Sie die folgenden Sicherheitshinweise, um Fehlfunktionen, Schäden oder Verletzungen zu vermeiden:

Bitte verwenden Sie dieses Produkt nur für die vorhergesehenen Funktionen.

Die geneigten Lautsprecherständer sind ideal, um das Klangerlebnis Ihrer Monitor-, Regal- oder Satellitenlautsprecher bei erhöhter Hörposition zu verbessern.

Der Ständer ist teilweise mit einer EVA-Moosgummibeschichtung versehen, um den daraufgestellten Lautsprechern besseren Halt zu geben und um Vibrationen zu minimieren.

Nutzen Sie die Stative nur für Lautsprecher deren Grundfläche sicher und stabil auf die Ablagefläche des Produktes passt und 20x20cm Bodenfläche sowie 6KG Maximalgewicht nicht überschreiten.

Die mittige Langloch-Aussparung ermöglicht es Lautsprecher, die mit Fixierungsgewinde im Boden ausgestattet sind, mit der Halterung zu verschrauben.



WARNUNG Sollten Sie Lautsprecher, die nicht über ein Verschraubungsgewinde verfügen fixieren wollen (z.B. per Spaxschrauben ö.ä.), so weisen wir darauf hin, dass dies auf eigene Gefahr geschieht. Prüfen Sie unbedingt **vor** dem Verschrauben, dass wichtige Bauteile/Komponenten im Lautsprecher nicht beschädigt werden!

Pronomic MSS-2014 Angled Foot Speaker Stand

Item number: 00095049 (1 pair black) Version: 05.2023

Thank you for choosing our speaker stand.

To ensure that you are fully satisfied with this product, please read carefully and understand this instruction manual before using our product. Keep these operating instructions in a safe place. The operating instructions must be passed on to all subsequent users.



Follow the operating instructions!



WARNING

This is not a toy. Please do not leave children unsupervised when handling this item.

All information in these operating instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damage in connection with the use of these operating instructions.

Detailed safety instructions/usage:



NOTE

Please observe the following safety instructions to avoid malfunctions, damage or injury:

Please use this product only for its intended functions.

The tilted speaker stands are ideal for enhancing the sound experience of your monitor-, shelf- or satellite speakers in an elevated listening position.

The stand is partially covered with an EVA foam rubber coating to provide better support for the speakers placed on it and to minimize vibrations.

Use the stands only for speakers whose base fits safely and stably on the support surface of the product and does not exceed 20x20cm base area and 6KG maximum weight.

The central slotted hole allows speakers equipped with fixing threads in the base to be screwed to the bracket.



WARNING If you want to fix speakers that do not have a screw thread (e.g. using Spax screws etc.), we would like to point out that this is done at your own risk. **Before** screwing, make sure that important parts/components in the loudspeaker are not damaged!