

EXPRESSION CONTROL

Rock foot back and forth to adjust overdrive.




HEEL DOWN — buffered original signal, no effect.



TOE DOWN — overdrive and boost levels will be at the maximum level set by their respective knobs

CONTROLS PANEL



CONTROLS

DRIVE knob will adjust the desired amount of overdrive.

TONE knob will adjust the desired amount of high end roll off.

BOOST knob will adjust the toe down position from unity gain, to a desired "solo" gain of over 5dB above unity.

1/0

INPUT connects to instrument with 1/4" mono instrument cable (Input impedance $1M\Omega$).

9V connects to a power adapter via the standard 5.5/2.1mm DC jack (center pin negative; 18mA current consumption).

OUTPUT connects to amplifier with 1/4" mono instrument cable (Output impedance <10K Ω).

LIMITED WARRANTY

Ernie Ball, Inc. will guarantee your Ernie Ball pedal for 6 months from the date of original purchase against defects in workmanship and materials. If a defect arises, the pedal will be repaired without charge if delivered FREIGHT PREPAID to the following address. It will be returned to you freight prepaid when repair is complete. It is not necessary to mail a warranty card to us; however, claim must be accompanied by PROOF OF PURCHASE in the form of a legible photocopy of your original sales slip showing where you bought it.

WE WILL NOT WARRANT YOUR E.B. PEDAL IF: Alterations, modifications, or add-ons have been made. Unauthorized repairs have been performed or attempted. Damage is caused by mistreatment or accident. United Parcel Service is recommended for shipping returns. ERNIE BALL INC/Pedal Rebuilds 53-973 Polk St. Coachella, CA 92236

FOR MORE INFORMATION ON PEDAL REBUILDS